

ADHEMESH | Bi-Component Sticker

INDICATION

Adhesive suitable for attaching technical fabrics (polyester, nylon and metallic) to metal or wooden frames.

PRODUCT

Bi-component adhesive:

Set of 750 ml adhesive and 150 ml hardener (Fast or Normal)

1: 5 - For 100 ml of adhesive, add 20 ml of hardener.

CHARACTERISTICS

- High quality adhesive for high tension;
- The Fast Hardener has a lower drying time, allowing greater productive speed of the pictures;
- The Normal Hardener is indicated for climates more durability of the product after mixing;
- Can be used for any type of ink Serigraphic



POT-LIFE and CURE (POLYMERIZATION) One of the main advantages of ADHEMESH is its POT-LIFE. A after mixing with the Quick Hardener, we recommend to use the product in a maximum of 6 to 7 hours, after this time there will be loss of quality and change of viscosity. The complete polymerization is after 24 hours of application.

For the Normal hardener, we recommend to consume a maximum of 2 to 3 hours. Its total polymerisation is also 24 hours.

INSTRUCTIONS FOR USE

Preparation:

The two components should be mixed as indicated (1: 5) in an impurity-free container. Complete homogenization is achieved by color uniformity.

The frame (frame) must be completely clean, free of grease, oxidation or any kind of impurities. If it is aluminum frame, they should be sanded to create a rough surface.

Application:

- The **frame (frame)**(you can use **cadre (frame)**) is placed in the stretching equipment. We recommend applying (by brush) the adhesive (already prepared) to the frame without the adhesive, especially if it is to stretch a fabric of 100 threads / cm or more;

- The fabric must be perfectly evenly stretched over the frame. Always the fabric should be in perfect contact with the frame. We recommend the use of weights inside the frame to further improve this contact;

- Apply the Adhesive (already mixed with the Hardener) using a soft brush. Allow to dry approximately 15 to 25 minutes (fast) and 30 to 40 minutes (normal), depending on the ambient temperature, tissue opening, applied layer of the The relative humidity of the air.

Note: The total ADHESIVE Cure will be after 24 hours.

Care

Use always has PPE during the handling of the Product. View as tabs (MSDS) Before Using OS Products. How INFORMATION In This Container Bulletin Technical were obtained tested Realized in our Laboratory, we recommend always tested before using the PRODUCT in scale.

PRODUCT ONLY Professional for use.